



- 28. 흑막 (BLACK CYCLORAMA)
- 27. 하늘막 (CYCLORAMA)
- 26. 골막 3 + 머리막 6 (#3 DRAW CURTAIN + #6 HOUSE BORDER)
- 25. 장치봉 14 (#14 SET BATTEN)
- 24. 하늘막상단조명 + 머리막 5 (SKY CYC. LIGHT + #5 HOUSE BORDER)
- 23. 장치봉 13 (#13 SET BATTEN)
- 22. 장치봉 12 (#12 SET BATTEN)
- 21. 장치봉 11 (#11 SET BATTEN)
- 20. 조명봉 3 + 머리막봉 (#3 LIGHT BATTEN + HOUSE BORDER BATTEN)
- 19. 장치봉 10 (#10 SET BATTEN)
- 18. 장치봉 9 (#9 SET BATTEN)
- 17. 골막 2 + 머리막 4 (#2 DRAW CURTAIN + #4 HOUSE BORDER)
- 16. 장치봉 8 (#8 SET BATTEN)
- 15. 장치봉 7 (#7 SET BATTEN)
- 14. 장치봉 6 (#6 SET BATTEN)
- 13. 천장음향반사판 2 (#2 ACOUSTICAL SHELL-CEILING)
- 12. 조명봉 2 + 머리막봉 (#2 LIGHT BATTEN + HOUSE BORDER BATTEN)
- 11. 장치봉 5 (#5 SET BATTEN)
- 10. 영상막 (SCREEN)
- 09. 골막 1 + 머리막 3 (#1 DRAW CURTAIN + #3 HOUSE BORDER)
- 08. 장치봉 4 (#4 SET BATTEN)
- 07. 장치봉 3 (#3 SET BATTEN)
- 06. 천장음향반사판 1 (#1 ACOUSTICAL SHELL-CEILING)
- 05. 조명봉 1 + 머리막 2 (#1 LIGHT BATTEN + #2 HOUSE BORDER)
- 04. 장치봉 2 (#2 SET BATTEN)
- 03. 장치봉 1 (#1 SET BATTEN)
- 02. 면막 + 머리막 1 (HOUSE CURTAIN + #1 HOUSE BORDER)
- 01. 방화막 (SAFETY CURTAIN)
- 00. 영점선 (ZERO LINE)
- 01. 앞무대조명 1 (#1 APRON LIGHT)
- 02. 현수막봉 (PLACARD BATTEN)